







# Oil drain pump for DT4.70 & DTA4.85

08-00161

Installatie instructies  
Installation instructions  
Installationsvorschriften  
Instructions d'installation  
Instrucciones de instalación  
Istruzioni per l'installazione



**Vetus** n.v.

FOKKERSTRAAT 571 - 3125 BD SCHIEDAM - HOLLAND - TEL.: +31 10 4377700  
TELEFAX: +31 10 4372673 - 4621286 - E-MAIL: sales@vetus.nl - INTERNET: <http://www.vetus.com>

Printed in the Netherlands  
363299.01 06-10